

Hydrogen Peroxide Test Strips Measuring the HP levels in water



What: Hydrogen Peroxide Test Strips

Where: Any water sample.

When: Anytime. Depending on why you're testing the water, it may be correct to test just before or just after a disinfection.

Why: Hydrogen Peroxide Test Strips allow you to measure the levels of hydrogen peroxide in any water sample. Use them in conjunction with, and as instructed by, the EndoSan Help Sheets.

How:

Step 1) Take the test strip from its container and simply dip into the water you wish to test; or hold under the running water you wish to test.

Step 2) Check the test strip against the colour coded scale on the back of the container. Use the appropriate Help Sheet to guide you with regards to what exactly you're looking for.