

High Level Hydrogen Peroxide Test Strips Measuring the HP levels in water 0-1000ppm



What: High level hydrogen peroxide strips measuring 0-1000ppm hydrogen peroxide

Where: Any water sample with levels of hydrogen peroxide up to 1000ppm. This can be any brand of hydrogen peroxide or silver, stabilised hydrogen peroxide. In a water system the far and the near points of system (sentinels) would be checked as a minimum.

When: Anytime. Levels would be checked after the hydrogen peroxide was added to the system and then after 1 hour. Levels may also be checked as the hydrogen peroxide is removed from the system. These test strips are ideal for a High Level Disinfection at 1000ppm peroxide/2000ppm Huwa-San.

Why: Hydrogen Peroxide Test Strips allow you to measure the levels of hydrogen peroxide in any water samples. Use them in conjunction with, and as instructed by, the Huwa-San Help Sheets.

How:

Step 1) Take the test strip from its container and simply dip into the water you wish to test; or hold under the running water you wish to test for 1 second.

Step 2) Shake off excess liquid.

Step 3) After 5 seconds, check the test strip against the colour coded scale on the back of the container. The scale for the high level peroxide test strips goes up in increments of 0, 50, 150, 300, 500, 800, 1000ppm peroxide.

Please note that there are two blocks on this strip. The one closest to the base of the strip provides the reading and the one above the strip only changes colour where overdosing has occurred i.e. the peroxide level is above 1000ppm.